




AO90MPBMF, AO90MPAMF
AOG90MPBMF, AOG90MPAMF




AO90MPBMF, AO90MPAMF
AOG90MPBMF, AOG90MPAMF



AO90MPBMF, AO90MPAMF
AOG90MPBMF, AOG90MPAMF



AO90MPBMF, AO90MPAMF
AOG90MPBMF, AOG90MPAMF



AO90MPBMF, AO90MPAMF
AOG90MPBMF, AOG90MPAMF

Ref	Description	Part No.		Ref	Description	Part No.	
2	FAN COVER	9366142010		344	4-WAY VALVE	313943302804	
4	EMBLEM-REAR(FUJITSU)	9359836018		344-2	4-WAY VALVE	9353532008	
4	EMBLEM-REAR(GENERAL)	313791088308		354	PRESSURE SWITCH	9355094009	
9	REAR PANEL SUB ASSY	9362943024		355	BRACKET (CONDENSER)-L SUB ASSY	9362958011	
12	BASE ASSY	9372336021		356	BRACKET (CONDENSER)-R SUB ASY	9362959018	
13	3-WAY VALVE ASSY	9368997007		361	BUSHING	9361725003	
15	STRAINER	9371191010		376	BRACKET (CONTROL BOX)	9361727007	
15-1	JOINT PIPE (3WV) B2	9374744039		408	SPECIAL NUT M8	313252257701	
15-2	JOINT PIPE (3WV) B1	9374744022		450	DICHARGE PIPE ASSY	9375074012	
16-1	CONDENSER A ASSY	9370620023		453	RECEIVER TANK ASSY	9371740010	
16-2	CONDENSER B ASSY	9370621020		457-1	SOLENOID VALVE (SV1,2,3,4,5,6)	9703889028	
26	COMPRESSOR COVER-A	9361935006		457-2	SOLENOID VALVE (SV7, 8)	9703889011	
32	CONTROL BOX	9361713000		477	BELL-MOUTH	9361721005	
39	PROPELLER FAN	9361726000		527	CONDENSER GUARD	9366143017	
41	FAN MOTOR ASSY-OUTER	9601271017		560	FLANGE ASSY	9363035001	
42	BRACKET PANEL (MOTOR)	9361703001		564	BYPASS ASSY	9375081010	
45	BRACKET (MOTOR)	9361701007		595	SUC PIPE N ASSY	9363929003	
46-1	COMPRESSOR A ASSY	9367379002		596	SUC PIPE Y ASSY	9365436004	
46-2	COMPRESSOR B ASSY	9367380008		599	SIGNAL PCB ASSY	9704424044	
46-3	COMPRESSOR C ASSY	9367381005		621	SUC PIPE S ASSY	9365071007	
64	CAPACITOR (FAN MOTOR)	9703306037		646	COMPRESSOR COVER-B	9361936003	
85	VALVE PLATE	9363063004		678	BRACKET (THERMISTOR)	313557406106	
86	GASKET	9363272000		735-1	DISTRIBUTOR A ASSY	9361906006	
87	BRACKET (COMPRESSOR)	9361694002		735-2	INLET PIPE(CONDENSER)C ASSY	9363953008	
100	BASE FOOT	9361688025		737	SUC PIPE K ASSY	9363934007	
117-3	SPECIAL WASHER M6	313306391007		761	SIDE PANEL-R.SUB ASSY	9362941020	
121	BALL VALVE JNT PP B ASSY	9371733012		761-1	PLUGGING PIPE A	9375078072	
132	FRONT PROTECTION NET	9366144014		761-2	PLUGGING PIPE	9375078065	
133	FRONT PANEL-L PAINTED	9361709027		762	SIDE PANEL-L. SUB ASSY	9362940016	
134	FRONT PANEL-R SUB ASSY	9362965330		765	DRAIN PIPE.(I-TYPE)	9301102000	
149	CONDENSING PIPE P ASSY	9364952000		790-1	BELT HEATER-A	9361140097	
149-1	CONDENSING PIPE F ASSY	9365439005		790-2	BELT HEATER-B	9361140080	
150	HALF UNION-B	9357351018		790-3	BELT HEATER-C	9361140073	
160	DRAIN PAN SUB ASSY	9362961011		791	MAGNETIC RELAY	9900227012	
164	SEPARATE WALL UP SUB ASSY	9362942027		810-1	BALL VALVE-B (R407C)	9362579001	
166	SEPARATE WALL-L	9361695009		810	BALL VALVE-B (R407C)	9361938007	
167	SEPARATE WALL-R SUB ASSY	9362948029		815-1	TERMINAL 5P	9363275018	
175	BRKT PNL (S VLV)	9364230009		815-2	TERMINAL 3P	9363276046	
176	BRACKET (VALVE)-A	9368955007		825	EXPANSION VALVE ASSY	9366067009	
185	RUBBER BUSHING	313005066051		825-1	EXPANSION VALVE	9361929005	
226	REINFORCEMENT SEPAWALL)SUB ASY	9362949026		825-2	EXPANSION VALVE	9363294002	
236	CONTROLLER PCB ASSY	9704157027		829-1	JOINT PIPE A ASSY	9363994001	
253-1	THERMISTOR ASSY	9900326012		829-3	JOINT PIPE (SUB COOL) A	9371728025	
253-1	WIRE WITH CONNECTOR	9703878015		829-5	JOINT PIPE D	9363932003	
253-2	TERMISTOR ASSY	9900328016		829-7	JOINT PIPE F ASSY	9363912005	
253-2	WIRE WITH CONNECTOR	9703879012		829-8	JOINT PIPE G ASSY	9364022000	
253-3	THERMISTER SPRING	9300089012		829-9	JOINT PIPE H ASSY	9364017006	
267	INSULATION (PIPE)-C	313005074759		829-13	JOINT PIPE M	9365017005	
289	RINFORCEMENT SIDE PANEL SUB ASY	9362955010		829-14	JOINT PIPE L	9365016008	
310	COMPRESSOR COVER	9366132004		833	AUXILIARY PIPE ASSY	9363891003	
330-6	BYPASS JOINT PIPE F	9375092047		846	RELAY	9900295011	
330-7	JOINT PIPE (BYP) J	9375091026		880-1	NETWORK (C-R)	9700987017	
331	SUCTION PIPE A ASSY	9375087081		890	BRKT PNL (COMP) ASSY	9364208008	
331-1	SUCTION PIPE ASSY (2HP)	9375076016		914-1	OIL SEPARATOR A ASSY	9371742014	
331-2	SUCTION PIPE ASSY (4HP)	9375076023		915-1	PRESSURE SENSOR	9703890000	
331-3	SUCTION PIPE ASSY (6HP)	9375076030		919-1	COIL (EXPANSION VALVE 2)	9366344001	
332	JOINT PIPE (COMP) A	9375078010		919-2	COIL (EXPANSION VALVE 3)	9366345008	
332-1	JOINT PIPE (COMP) B	9375078027		919-3	COIL (EXPANSION VALVE 1)	9361930001	
333	ACCUMULATOR ASSY	9375073015		942	CONTROL BOX COVER SUB ASY	9362950114	
343-1	SOLENOID SV1 (WHITE)	9703888014		982-1	CORD CLAMP	9356857009	
343-2	SOLENOID SV2 (RED)	9703888021		982-2	CORD CLAMP-B	9356858006	
343-3	SOLENOID SV3 (YELLOW)	9703888038			VARISTER	0000361224	
343-4	SOLENOID SV4 (RED)	9703888045			ARRESTER	0600280154	
343-5	SOLENOID SV5 (GREEN)	9703888052			FUSE	0600222574	
343-6	SOLENOID SV6 (WHITE)	9703888069					
343-7	SOLENOID SV7 (BLUE)	9703888076					
343-8	SOLENOID SV8 (BLACK)	9703888083					
343-10	SOLENOID 4WV2 (YELLOW)	9970034060					
343-11	SOLENOID 4WV3 (RED)	9970034046					
343-12	SOLENOID 4WV4 (GREEN)	9970034053					